

## Alphabetical index

## Alphabetical index

<b>A</b>	A/C .....	217
	ABS.....	184
	ACCESSORY mode .....	122
	Active stabilizer suspension	
	system.....	184
	Adaptive variable	
	suspension system .....	183
	Air conditioning system	
	Air conditioning filter .....	437
	Automatic air conditioning	
	system.....	217
	Airbags	
	Airbag operating conditions.....	83
	Airbag precautions for	
	your child.....	87
	Airbag warning light .....	489
	Curtain shield airbag	
	precautions .....	90
	General airbag precautions .....	87
	Locations of airbags.....	80
	Modification and disposal of	
	airbags.....	91
	Proper driving posture .....	78
	Side airbag precautions.....	87
	Side and curtain shield airbags	
	operating conditions .....	83
	SRS airbags .....	80
	Alarm .....	75
	Antenna .....	235
	Anti-lock brake system .....	184
	Armrest.....	356
	Ashtrays.....	351

Audio system	
Antenna.....	235
AUX adapter .....	287
Cassette player .....	238
CD player/changer.....	242
DVD information .....	270
DVD player/changer .....	251
DVD video/audio.....	254
MP3/WMA disc.....	247
Optimal use .....	282
Radio .....	229
Steering switches .....	288
Video CD .....	266
Automatic headlight leveling	
system .....	144
Automatic light control system.....	142
Automatic transmission	
If the shift lever cannot be	
shifted from "P" .....	524
Mode select switch .....	126
S mode .....	127
AUX adapter .....	287

<b>B</b>	Back-up lights	
	Wattage.....	552
	Battery	
	12 volt battery .....	417
	Checking.....	417
	If the 12 volt battery is	
	discharged .....	529
	Preparing and checking	
	before winter.....	199
	Bluetooth® .....	296

Brake		Seat heater precautions.....	355
Fluid.....	416	Trunk precautions.....	44
Parking brake.....	131	Cigarette lighter.....	352
Brake assist.....	184	Cleaning	
		Exterior.....	388
<b>C</b> Care		Interior .....	391
Exterior.....	388	Seat belts.....	392
Interior.....	391	Clock .....	349
Seat belts.....	392	Coin holder .....	345
Cargo capacity .....	194	Compass .....	369
Cargo hooks .....	360	Condenser .....	415
CD player/changer .....	242	Console box .....	342
Chains.....	200	Cooling system	
Child-protectors .....	38	Engine overheating.....	533
Child restraint system		Cruise control	
Definition.....	98	Cruise control.....	150
Installation.....	102	Dynamic radar cruise control.....	153
Installing CRS with lower		Cup holders .....	345
anchors.....	106	Curtain shield airbags.....	80
Installing CRS with seatbelts .....	103	Customizable features .....	569
Installing CRS with top straps.....	107		
Child safety		<b>D</b> Daytime running light system .....	143
Airbag precautions .....	87	Defogger	
Battery precautions.....	419, 532	Rear window .....	225
Child restraint system .....	98	Side mirror.....	225
Child-protectors.....	38	Dimension.....	540
How your child should wear		Dinghy towing .....	205
the seatbelt.....	56	Display	
Installing child restraints.....	102	Multi-information display .....	139
Moon roof precautions .....	69	Touch screen .....	208
Power window lock switch .....	64	Trip information .....	140
Power window precautions.....	64	Warning message.....	497
Removed electronic key battery		Do-it-yourself maintenance .....	400
precautions .....	441	Door courtesy lights .....	337
Seat belt comfort guide.....	54	Door pocket.....	346
Seat belt precautions.....	57		

## Alphabetical index

### Doors

- Door lock..... 22, 34, 37
- Rear door child protector ..... 38

### Driver's seat belt reminder light ..... 490

### Driver's seat position memory ..... 47

### Driving

- Correct posture ..... 78
- Procedures ..... 112

### DVD player/changer ..... 251

## **E** Electric power steering ..... 184

### Electronic key

- If the electronic key does  
not operate properly ..... 526
- Replacing battery ..... 440

### Emergency, in case of

- If a warning light turns on ..... 488
- If a warning message is  
displayed ..... 497
- If the electronic key does  
not operate properly ..... 526
- If the engine will not  
start ..... 523
- If the shift lever cannot be  
shifted from "P" ..... 524
- If the 12 volt battery is  
discharged ..... 529
- If you have a flat tire ..... 512, 522
- If you lose your keys ..... 525
- If you think something is  
wrong ..... 484
- If your vehicle becomes stuck ..... 536
- If your vehicle needs to be  
towed ..... 478
- If your vehicle overheats ..... 533

### Engine

- ACCESSORY mode ..... 122
- Compartment ..... 406
- Engine (ignition) switch ..... 121
- Hood ..... 403
- How to start the engine ..... 121
- If the engine will not start ..... 523
- Overheating ..... 533

### Engine compartment cover ..... 408

### Engine coolant temperature

- gauge ..... 132

### Engine coolant

- Capacity ..... 546
- Checking ..... 414
- Preparing and checking  
before winter ..... 199

### Engine oil

- Capacity ..... 544
- Checking ..... 409
- Preparing and checking  
before winter ..... 199

### Engine oil maintenance data ..... 412

### Engine (ignition) switch ..... 121

### Event data recorder ..... 486

## **F** First-aid kit storage belt ..... 360

### Floor mats ..... 359

### Fluid

- Brake ..... 416
- Washer ..... 420

### Fog lights

- Switch ..... 145
- Wattage ..... 552

### Foot light ..... 337

Front passenger occupant classification system ..... 92	Headlights Adaptive front lighting system..... 143
Front passenger's seat belt reminder light ..... 490	Discharge headlights precautions.....475
Front seats Adjustment ..... 45	Replacing light bulbs .....470
Driver's seat position memory .....47	Switch.....142
Front turn signal lights Wattage .....552	Wattage.....552
Fuel Capacity.....543	Heaters Seat heaters .....354
Fuel gauge.....132	Side mirror.....225
Gas station information .....596	Hill-start assist control .....184
Information.....553	Hood.....403
Refueling.....70	Hooks Cargo .....360
Fuel door.....70	Shopping bag .....360
Fuel filler door.....70	
Fuses.....442	<b>I</b> Identification Engine.....542
<b>G</b> Garage door opener.....363	Vehicle .....541
Gas station information .....596	Ignition switch Engine switch.....121
Gauges.....132	Illuminated entry system .....337
Glove box .....341	I/M test.....399
<b>H</b> Hands-free system (for cellular phone).....291	Immobilizer system.....73
Head restraints.....51	Indicator lights.....136
Headlight aim .....467	Initialization Items to initialize .....575
Headlight cleaner .....149	Inside rear view mirror .....61
	Instrument panel light control .....133
	Interior lights Interior lights.....338
	Wattage.....552
	Intuitive parking assist .....164

## Alphabetical index

### J

#### Jack

Positioning a floor jack.....404

Replacing the wheel.....512

Jack handle.....512

### K

Keyless entry.....34

#### Keys

Engine (ignition) switch.....121

If the electronic key does  
not operate properly.....526

If you lose your keys.....525

Key number plate.....20

Keys.....20

Mechanical key.....20

Wireless remote control key.....34

### L

Lexus Link System.....373

#### Light bulbs

Replacing.....470

Wattage.....552

Light sensitive optitron meter.....134

#### Lights

Fog light switch.....145

Headlights switch.....142

Interior lights list.....337

Replacing light bulbs.....470

Turn signal lever.....130

Vanity lights.....348

Wattage.....552

### M

#### Maintenance

Do-it-yourself maintenance.....400

General maintenance.....396

Maintenance data.....540

Maintenance requirements.....394

#### Meter

Instrument panel light control.....133

Meters.....132

Micro dust and pollen filter.....221

#### Mirrors

Inside rear view mirror.....61

Side mirror heater.....225

Side mirrors.....62

Vanity mirrors.....348

Moon roof.....67

MP3 disc.....247

Multi-information display.....139

### O

Odometer.....132

#### Oil

Engine oil.....409

#### Opener

Fuel filler door.....70

Hood.....403

Trunk.....42

Outer foot lights.....337

#### Outside rear view mirrors

Adjusting and folding.....62

Mirror position memory.....47

#### Outside temperature

display.....140, 350

Overhead console.....343

Overheating, Engine.....533

<b>P</b>	Parking brake .....	131
	Parking lights	
	Replacing light bulbs .....	470
	Switch .....	142
	Wattage .....	552
	Personal lights .....	339
	Power outlet .....	353
	Power windows .....	64
	Pre-collision system .....	190
<b>R</b>	Radar cruise control .....	153
	Radiator .....	415
	Radio .....	229
	Radio data system .....	231
	Rear sunshade .....	357
	Rear turn signal lights	
	Replacing light bulbs .....	470
	Wattage .....	552
	Rear view monitor system .....	179
	Rear window defogger .....	225
	Replacing	
	Electronic key battery .....	440
	Fuses .....	442
	Light bulbs .....	470
	Reporting safety defects for	
	U.S. owners .....	578
<b>S</b>	Seat belts	
	Adjusting the seat belt .....	53
	Automatic locking retractor .....	55
	Child restraint system	
	installation .....	102
	Cleaning and maintaining	
	the seat belts .....	392
	Emergency locking retractor .....	55
	How to wear your seat belt .....	53

How your child should wear	
the seat belt .....	56
Pre-collision seat belts .....	55
Pregnant women,	
proper seat belt use .....	55
Reminder light .....	490
Seat belt extenders .....	56
Seat belt pretensioners .....	54
Seat heaters/ventilators .....	355
Seating capacity .....	198
Seats	
Adjustment .....	45
Adjustment precautions .....	46
Child seats/child restraint	
system installation .....	102
Cleaning .....	391
Driver's seat position memory .....	47
Head restraint .....	51
Properly sitting in the seat .....	78
Seat heaters .....	354
Service reminder indicators .....	136
Shift lever	
Automatic transmission .....	125
If the shift lever cannot be	
shifted from "P" .....	524
Shift lock system .....	524
Shopping bag hooks .....	360
Side airbags .....	80
Side marker lights	
Switch .....	142
Side mirror	
Adjusting and folding .....	62
Mirror position memory .....	47

## Alphabetical index

Smart access system with push-button start	
Antenna location.....	24
Entry function.....	22
Starting the engine.....	121
Spare tire	
Inflation pressure.....	550
Spare tire.....	513
Spark plug.....	546
Specifications .....	540
Speedometer.....	132
Steering wheel	
Adjustment.....	60
Audio switches .....	288
Steering wheel position memory.....	47
Storage compartment .....	344
Storage feature.....	340
Stuck	
If your vehicle becomes stuck.....	536
Sun visors .....	347
Switch	
"ENGINE START STOP" switch .....	121
Fog light switch.....	145
Ignition switch.....	121
Light switches.....	142
Mode select switch.....	126
Power door lock switch.....	37
Power window switch.....	64
Tire pressure warning reset switch .....	422
Tire pressure warning select switch.....	424
Window lock switch .....	64
Wipers and washer switch.....	146

<b>T</b> Tachometer .....	132
Tail lights	
Switch.....	142
Theft deterrent system	
Alarm.....	75
Immobilizer system .....	73
Theft prevention labels.....	77
Tire inflation pressure .....	550
Tire information	
Glossary .....	562
Size.....	559
Tire identification number.....	558
Uniform Tire Quality Grading...	560
Tires	
Chains.....	200
Checking.....	421
Compact spare tire.....	513
If you have a flat tire .....	512, 522
Inflation pressure .....	550
Information .....	556
Replacing .....	512
Rotating tires.....	421
Size.....	550
Snow tires.....	202
Tire pressure warning system.....	421
Tools.....	512
Total load capacity .....	198
Touch screen.....	208
Towing	
Dinghy towing .....	205
Emergency towing .....	478
Trailer towing .....	204
Traction control.....	184
Trip meter .....	132

<b>Trunk</b>	
Opener.....	42
Trunk light .....	43
Wattage .....	552
<b>Turn signal lights</b>	
Replacing light bulbs .....	470
Switch.....	130
Wattage .....	552

**V**

<b>Vanity lights</b>	
Vanity lights.....	348
Wattage .....	552
<b>Vanity mirrors.....</b>	<b>348</b>
<b>Variable gear ratio steering .....</b>	<b>185</b>
<b>Vehicle dynamics</b>	
integrated management .....	185
<b>Vehicle identification number .....</b>	<b>541</b>
<b>Vehicle load limits.....</b>	<b>198</b>
<b>Vehicle stability control.....</b>	<b>184</b>
<b>Ventilators.....</b>	<b>354</b>

**W**

<b>Warning buzzers</b>	
Brake system.....	488
Downshifting.....	128
Open door .....	490
Seat belt reminder .....	490
<b>Warning lights</b>	
Anti-lock brake system .....	489
Brake system .....	488
Charging system .....	488
Electric power steering	
warning light.....	489
Electronically	
controlled brake system/	
Vehicle stability control .....	489
Low fuel level.....	490

Malfunction indicator lamp.....	489
Master warning light.....	491
Open door.....	490
Pre-collision system.....	489
Seat belt reminder light.....	490
SRS airbags.....	489
Tire pressure warning light .....	490

**Warning messages**

Anti-lock brake system .....	501
Brake assist .....	501
Dynamic radar	
cruise control.....	500
Engine oil level .....	504
Engine oil maintenance .....	504
Engine oil pressure .....	497
Headlight.....	498
Hill-start assist control .....	501
Hood.....	502
Intuitive parking	
assist.....	499, 505, 507
Moon roof .....	503
Open door.....	502
Parking brake .....	503
Pre-collision system.....	499, 505
Rear lights system.....	498
Smart access system with	
push-button start .....	508
Steering lock.....	498, 510
Tire pressure warning	
system .....	498, 504
TRAC.....	501
Trunk .....	503
VGRS.....	501
VSC/ECB.....	501
Washer fluid .....	503



## Alphabetical index

<b>Washer</b>	
Checking .....	420
Preparing and checking	
before winter .....	199
Switch .....	146
<b>Washing and waxing .....</b>	<b>388</b>
<b>Weight</b>	
Cargo capacity .....	194
Load limits .....	198
Weight .....	540
<b>Wheels .....</b>	<b>435</b>
<b>Window glasses .....</b>	<b>37</b>
<b>Window lock switch .....</b>	<b>37</b>
<b>Windows</b>	
Power windows .....	64
Rear window defogger .....	225
Washer .....	146
<b>Windshield wipers</b>	
Position .....	201
Windshield wipers .....	146
<b>Winter driving tips .....</b>	<b>199</b>
<b>Wireless remote control key</b>	
Locking/Unlocking .....	34
Replacing the battery .....	440
<b>WMA disc .....</b>	<b>247</b>

